

Für die Übertragung steht Ihnen folgender Frequenzbereich zur Verfügung:

Frequenzbereich	Bandbreite	Anzahl Frequenzen
734 - 776 MHz	42 MHz	max. 1680

Die Sender und Empfänger verfügen über jeweils 20 Kanalbänke, auf denen werksseitig Frequenz-Presets voreingestellt sind. Innerhalb einer Kanalbank sind die Frequenz-Presets untereinander intermodulationsfrei. Sie sind nicht veränderbar.

In der Kanalbank **U** können Sie in 25-kHz-Schritten Frequenzen frei einstellen und abspeichern. Diese sind unter Umständen nicht intermodulationsfrei.

Die Frequenz-Presets in den Kanalbänken **1** bis **20** sind in der Tabelle auf den Innenseiten dargestellt.

#### Rahmenbedingungen und Einschränkungen für die Nutzung von Frequenzen

In Ihrem Land gelten möglicherweise gesonderte Rahmenbedingungen und Einschränkungen für die Nutzung von Frequenzen.

Informieren Sie sich vor der Inbetriebnahme des Produktes unter folgender Adresse:

[www.sennheiser.com/frequency-information](http://www.sennheiser.com/frequency-information)

Transmitters and receivers are available in the following frequency range:

Frequency range	Bandwidth	Number of frequencies
734 - 776 MHz	42 MHz	max. 1680

Transmitters and receivers have 20 frequency banks respectively. Each of the channels in the frequency banks has been factory-preset to a frequency. These frequency presets within one frequency bank are intermodulation-free. They cannot be changed.

The frequency bank **U** allows the user to store individual frequencies which are freely selectable in 25-kHz steps. It might be that these frequencies are not intermodulation free.

The table printed inside lists the frequency presets in the frequency banks **1** to **20**.

#### Conditions and restrictions for using frequencies

There may be special conditions and restrictions for using frequencies in your country.

Before putting the product into operation, find the information for your country at the following address:

[www.sennheiser.com/frequency-information](http://www.sennheiser.com/frequency-information)



## 734 - 776 MHz

### Frequenzbereich C / Frequency range C

#### Zusatzinformationen für Systeme der Serie evolution wireless 100 G4

#### Additional information for Sennheiser evolution wireless 100 G4 systems

## Frequenzbereich C / Frequency range C: 734 - 776 MHz

### EBU TV Channels

CH 54: 734 - 742 MHz	CH 55: 742 - 750 MHz	CH 56: 750 - 758 MHz
CH 57: 758 - 766 MHz	CH 58: 766 - 774 MHz	CH 59: 774 - 782 MHz

Channel	Bank 1	Bank 2	Bank 3	Bank 4	Bank 5	Bank 6	Bank 7	Bank 8	Bank 9	Bank 10
1	734.200	742.200	750.200	758.200	766.200	734.200	742.200	750.200	758.200	734.200
2	734.600	742.600	750.600	758.600	767.400	734.600	742.600	750.600	758.600	735.400
3	735.200	743.200	751.200	759.200	769.000	735.200	743.200	751.200	759.200	737.000
4	736.000	744.000	752.000	760.000	771.200	736.000	744.000	752.000	760.000	739.000
5	737.200	745.200	753.200	761.200	774.200	737.200	745.200	753.200	761.200	741.200
6	739.600	747.600	755.600	763.600	774.600	738.800	746.800	754.800	762.800	750.600
7	741.800	749.800	757.800	765.800	775.200	742.600	750.600	758.600	766.600	753.200
8	740.900	748.900	756.900	764.900	776.000	743.900	751.900	759.900	767.900	756.200
9	736.475	744.475	752.475	760.475	766.950	746.600	754.600	762.600	770.600	766.200
10	738.125	746.125	754.125	762.125	768.050	747.100	755.100	763.100	771.100	766.600
11	738.575	746.575	754.575	762.575	769.500	748.800	756.800	764.800	772.800	767.200
12	740.475	748.475	756.475	764.475	772.250	749.500	757.500	765.500	773.500	768.000

Channel	Bank 11	Bank 12	Bank 13	Bank 14	Bank 15	Bank 16	Bank 17	Bank 18	Bank 19	Bank 20
1	742.200	734.200	742.200	734.600	742.200	734.200	742.200	750.200	758.200	766.200
2	743.400	734.600	742.600	735.200	742.600	736.400	744.400	752.400	760.400	768.400
3	745.000	735.200	743.200	736.000	743.200	738.800	746.800	754.800	762.800	770.800
4	747.000	736.000	744.000	737.200	744.000	740.000	748.000	756.000	764.000	772.000
5	749.200	737.600	745.600	738.800	745.200	740.800	748.800	756.800	764.800	772.800
6	758.600	739.800	747.800	741.000	746.800	741.400	749.400	757.400	765.400	773.400
7	761.200	758.200	766.200	766.200	749.100	741.800	749.800	757.800	765.800	773.800
8	764.200	759.400	767.400	766.600	774.200	735.100	743.100	751.100	759.100	766.700
9	774.200	761.100	769.100	769.600	774.625	735.525	743.525	751.525	759.525	769.900
10	774.600	763.000	771.000	770.600	775.250	737.425	745.425	753.425	761.425	774.350
11	775.200	765.100	773.100	767.300	775.700	737.875	745.875	753.875	761.875	775.050
12	776.000	765.600	773.600	769.100		739.525	747.525	755.525	763.525	